


Technical Description and User Manual



Teufel CAGE

Headphones with headset function

Teufel

General notes and information

Notice

The information in this document may change without prior notice and in no way constitutes any liability on the part of Lautsprecher Teufel GmbH.

No part of this user manual may be reproduced in any form or be broadcasted in any way electronically, mechanically, by photocopy or recording without the written permission of Lautsprecher Teufel GmbH.

© Lautsprecher Teufel GmbH
Version 1.1, July 2017

Contact

Please contact our customer service department with any questions, suggestions, or complaints:

Lautsprecher Teufel GmbH
BIKINI Berlin
Budapester Straße 44
10787 Berlin (Germany)

Telephone: +49 (0)30 - 217 84 217

**E-mail: service@teufelaudio.com
teufelaudio.com**

Original packaging

If you wish to exercise your eight-week right of return, we ask that you be absolutely sure to hold onto the packaging. We can only accept product returns with the ORIGINAL PACKAGING.

Empty boxes are not available!

Complaints

In case of a complaint we will need the following information to process your enquiry:

1. Invoice number

Can be found on the sales slip (enclosed with the product) or on the order confirmation received as a PDF document, e.g. 4322543

2. Serial number or batch number

Located on the back of the device, e.g. serial no.: UL 04007480121A

Thank you for your support!

Protecting the environment



Old devices must not be disposed of with household waste!

■ If the device is no longer operational, every consumer is required by law to dispose of used devices separately from household waste, e.g. at a collection point run by the communal authority/borough. This ensures that old devices are recycled in a professional manner and also rules out negative consequences for the environment.

For this reason, electrical equipment is labelled with the displayed symbol.

Package contents

- 1× headphones “Teufel CAGE”
- 1× microphone
- 1× USB cable, 3 m long
- 1× connector cable with two 3.5 mm jack plugs, 1.3 m long
- 1× storage box

For your safety

Please read



Before you use the headphones, please first carefully read through the safety notes and the user manual. This is the only way to use all functions safely and reliably.

Store the user manual in a safe place and also be sure to pass it on to any subsequent owner.

Proper use

The “Teufel CAGE” headphones are designed for the playback of audio and voice signals, which are transmitted with the help of the enclosed cable.

Only use the headphones as described in this user manual. Any other use will be deemed as not in accordance with the instructions and may lead to damage of property or even persons.

The manufacturer accepts no liability for damage caused by improper use.

The headphones are suitable for use at home, by DJs and professionals.



Safety notes

Danger of suffocation for children!

Make sure that children do not play with the packaging foil, do not pull small parts off of the headphones and put them in their mouth. There is a danger of suffocation.



Extended listening at high volumes may lead to hearing loss.

To avoid damage to health, avoid extended listening at high volumes.

Only connect headphones to the headphone outputs! Do not connect them to the speaker output of an amplifier.

Set the volume control of your audio source to a low level before you put on the headphones.

Risk in road traffic!

Your headphones significantly dampen external noise. Therefore, for reasons of road safety, do not wear your headphones whilst driving vehicles or cycling.

If you are a pedestrian, pay attention to your surroundings while wearing the headphones, especially when crossing the street.

Risk of injury!

Do not use your headphones in environments where there is a risk of explosion.

Risk of damage!

Ensure that the headphones do not become wet, protect them from moisture, heat (e.g. during the summer in cars) and mechanical influences (e.g. severe shocks, pressure and falling).

Always take hold of the plug when pulling out the connector cable. Do not pull on the cable.

Cleaning

Clean the ear cushions and the headband with a soft dry cloth. Never use aggressive cleaning agents as they may damage the sensitive surface.

Handling

Put your headphones on so that both ears are firmly covered.


If necessary, adjust the headband length to your head size.

Connecting with the USB cable



Use the enclosed USB cable to connect the headphones to a USB port on your PC.

Connecting with a 3.5 mm jack plug




Connect the 3.5 mm jack plug output of the headphones and the headphone jack of your audio system or your smart-phone using the enclosed connector cable.

The headphones have two 3.5 mm jack plug inputs. With this connection method, you can choose whether you would like to place the connector cable on the left or right.

Please keep in mind that the automatic left-right recognition of the headphones is only active if the connector cable is inserted in the respective backward 3.5 mm jack plug input.


Connecting a microphone



In order to be able to use the headphones as a headset, you must connect the microphone to a 3.5 mm jack plug

output of the headphones and connect the headphones to your PC or smart-phone with a USB or 3.5 mm jack plug cable.

Making phone calls with the CAGE



If your CAGE is connected to a PC, a compatible video game console or a compatible smartphone/mobile phone, you can make phone calls with the CAGE. To do so, connect the microphone to the headphones. Music playback will be interrupted in the event of an incoming call and a ring tone will sound instead.

The following functions are available to you with a USB connection to a PC or a compatible video game console:

Mute the current call.	Switch the microphone switch 1 .
Adjust the volume.	Set the volume control 3 towards "+" or "-".

Select the microphone input.	Move the microphone selector switch 4 up to select the USB connection or down to select the 3.5 mm jack plug connection.
------------------------------	---

If you would like to connect the headphones to a PC or a video game console via USB connection and to a smartphone/mobile phone via AUX connection simultaneously, you can select the microphone input with this function. Thus, your call will remain private in the event of an incoming call and will not be relayed to the PC or video game console.

Select the microphone input.	Move the microphone selector switch 4 up to select the USB connection or down to select the 3.5 mm jack plug connection.
------------------------------	---


If you would like to connect the headphones to a PC or a video game console via USB connection and to a smartphone/mobile phone via AUX connection simultaneously, you can select the microphone input with this function. Thus, your call will remain private in the event of an incoming call and will not be relayed to the PC or video game console.

The following functions are available when connected to a compatible smartphone/mobile phone via AUX:

Accept incoming call.	Briefly push the multifunction button 2 .
Reject incoming call.	Push and hold the multifunction button 2 .
End the current call.	Briefly push the multifunction button 2 .

Mute the current call.	Switch the microphone switch 1 .
Adjust the volume.	Set the volume control 3 towards "+" or "-".

Listening to music with the CAGE



If your CAGE is connected to a compatible smartphone or MP3 player, you can control the music playback via the CAGE.

The following functions are available for iOS:

Playback/stop music.	Push the multifunction button 2 1x.
Select the next music track.	Push the multifunction button 2 2x.
Select the previous music track.	Push the multifunction button 2 3x.
Access Siri.	Push and hold the multifunction button 2 1x.
Adjust the volume.	Move the volume control 3 towards “+” or “-”.

The following functions are available for Android:

Play back/stop music.	Push the multifunction button 2 1x.
Select the next music track.	Push the multifunction button 2 2x.

Access Google Search.	Push and hold the multifunction button 2 1x.
Adjust the volume.	Move the volume control 3 towards “+” or “-”.

Other functions

Lighting

The Teufel logo will illuminate in red as soon as the headphones have been connected via the USB cable.

Integrated sound card

The headphones have an integrated sound card. You can use the integrated sound card as soon as the headphones have been connected via the USB cable.

Software settings

Visit:

https://www.teufel.de/shop/support_product_detail.html?aid=16427&name=CAGE

or:

<https://www.teufel.de/kopfhoerer/cage-p16427.html>

to download the CAGE software.

With the CAGE software, you can configure different headphone and microphone settings (voice distorter, dual audio stream, sound settings).

Technical data

Driver unit:	Ø 40 mm
Max. power:	50 mW
Impedance:	32 Ω
Sensitivity at 1 kHz:	86 ±3 dB
Frequency response:	20–20000 Hz

You can find further technical data on our website.

Technical changes reserved!

 This device fulfils the applicable European and national guidelines. This is confirmed by the CE mark (the manufacturer has corresponding declarations on file).

Troubleshooting

The following advice should help you to solve problems.

If this does not help, you will find useful information in the detailed FAQs on our website. Otherwise, please contact our hotline (see page 1).

Problem	Possible cause	Solution
No audio playback.	The USB or 3.5 mm jack plug cable is not properly connected.	Properly connect the USB or 3.5 mm jack plug cable with the headphones.
	Volume has been set too low.	Increase the volume on the external player and/or headphones.
No voice reproduction.	The microphone switch is in the wrong position.	Switch the microphone switch.
	The microphone selector switch is in the wrong position.	Check whether the microphone selector switch is in the right position.

Please contact our customer service department with any questions, suggestions, or complaints:

Teufel

Lautsprecher Teufel GmbH
BIKINI Berlin
Budapester Straße 44
10787 Berlin (Germany)

Tel.: +49 (0)30 - 217 84 217
www.teufelaudio.com

No responsibility is assumed for
the correctness of this information.
Technical changes, typographical
errors and other errors reserved.

Manual No. 195340_20170728_UK